

Unit 3
 Models
 83402, 83412, 83432
 OBDII Installation
 (Supports Engine Data)

24/7
 Activation Hotline
 920.338.0479

Step 1: Mounting

- A. Find an open location on the top, roadside of the trailer nose. Do not install curbside.
- B. **IMPORTANT:** Ensure the mounting location is over a metal rail either from the outside or inside of the trailer. Device should be mounted to the **OUTSIDE** of the trailer only.
- C. Mark the location for each of the mounting bolts. There should be four (4) bolts and four (4) locknuts included.
- D. Drill holes into the locations marked in the previous step.
- E. Install the 4 bolts through the mounting holes of the device.
- F. Securely fasten to the trailer using the provided locknuts.



Step 2: Activation Magnet

- A. **IMPORTANT:** To enable tracking, you must remove the activation magnet from the top of the device. The device will not start tracking if the magnet is still in place.



Step 3: Verify the device is tracking

- A. Wait 5 minutes from the time the activation magnet was removed.
- B. Have the ESN number from the device available before contacting CyntrX.
- C. Email or call:
 - Email: activations@cyntrx.com
 - Call: (866) 312-3782